


First Connect BD Tuner Wireless Unit to speedo (to sensor port) and power on speedo.




1. On PC click bluetooth units



2. Choose add bluetooth-unit.



3. Select Next.



4. Choose the new unit ADVANCED-XXXX XXXX = number for your unit can be anything between 0000 to 9999



5. Use this key: 1234
Press next.



6. Remember the com-port (out going)
This is the one to use in AE BD TUNER software.
Press Finish!